

OPERATING and MAINTENANCE INSTRUCTIONS

Model: 120PH and 121PH “D” Series Proof/Hot Cabinets

| Model No. | Volts | Watts | Amps | Hertz | Phase | NEMA |
|---|-------|-------|------|-------|-------|-------|
| 120PH1836D 121PHUA11D 121PH1818D | 120 | 1920 | 16.6 | 60 | 1 | 5-20P |
| 120PH1836D208 121PHUA11D208 121PH1818D208 | 208 | 2000 | 9.6 | 60 | 1 | 6-15P |
| 120PH1836D240 121PHUA11D240 121PH1818D240 | 240 | 2000 | 8.6 | 60 | 1 | 6-15P |

All are designed for AC service.

HOW TO INSTALL UNIT:


1. Place cabinet near warm ovens. Do **NOT** put in drafty areas or near ventilating systems.
2. Plug cord end into proper wall outlet.
3. Fill water pan with 2 qts. (1.8 liters) of clean, hot water.

HOW TO PROOF:

1. Fill water pan (See “How to Install”)
2. Push “POWER” switch to “ON.” The yellow light will come on.
3. Push “MODE SELECTION” switch to “PROOF”. The yellow light will come on.
4. Turn “HUMIDITY” dial to No. 8.
5. Turn “AIR” dial to “OFF”.
6. Preheat for 30 minutes.
7. Put fresh or fully thawed dough into cabinet.

NOTE: The cabinet temperature will drop inside cabinet if cold dough is added.

Do NOT put frozen dough into cabinet



CONTROL PANEL PARTS IDENTIFICATION

- | | |
|--------------------------|----------------------------|
| 1. Switch - Power | 5. Yellow Light - Proof |
| 2. Yellow Light - Power | 6. Red Light - Heat |
| 3. Thermostat - Humidity | 7. Switch - Mode Selection |
| 4. Thermostat - Air | 8. Thermometer |

NOTE: No. 8 setting will give you an approximate temperature of 95°F (35°C), and 90-95% humidity. Experiment with different “HUMIDITY” and “AIR” settings to get the exact temperature and humidity you need. The thermometer shows the temperature inside the cabinet.

NOTE: Check water level in water pan if you are proofing longer than 90 minutes. Fill with clean, hot water.

| | |
|----------------------|----------------|
| Proof/Hot Cabinets | FL-2306 |
| Rev. 11 (10/2021) | Page 2 of 4 |

OPERATING and MAINTENANCE INSTRUCTIONS

Model: 120PH and 121PH “D” Series Proof/Hot Cabinets


HOW TO HOLD

1. Push “POWER” switch to “ON.” The yellow light will come on.
2. Push “MODE SELECTION” switch to “HEAT.” The red light will come on.
3. Turn “AIR” dial to temperature needed.

NOTE: No. 8 is about 175°F (79°C).
No. 6 is about 165°F (74°C).

Proper food holding temperature is 140°F (60°C) or higher.

4. Preheat cabinet for 30 minutes.
5. Put food into cabinet.



HOW TO TURN UNIT OFF:

Push “POWER” switch to “OFF” position.

HOT UNIT REMOVAL INSTRUCTIONS:

1. Unplug power cord from wall outlet.
2. Pull entire unit out the front of the cabinet.



BEFORE cleaning the cabinet:

1. Allow cabinet to cool.
2. Remove Hot unit from cabinet.
3. Do NOT use abrasives or harsh chemicals.



DELIME OR DESCALE RESERVOIR PARTS AS REQUIRED TO PREVENT DAMAGING BUILD-UP. WARRANTY COVERAGE MAY BE AFFECTED WITHOUT PROPER CLEANING.

HOW TO CLEAN THE CABINET:

- The door is a polycarbonate panel in a powder coated frame.
Use mild detergent and water, rinse and wipe dry with a soft cloth.
- The cabinet body (inside and outside) is aluminum.

THIS CABINET BODY IS INTENDED TO BE CLEANED USING HIGH PRESSURE CLEANING METHODS.

Wipe up spills as soon as possible and clean cabinet regularly to avoid heavy dirt build-up.

Detergents will assist in removing dirt, grease and stains. Only use detergents recommended for pressure washers.

- Empty water pan at least once a week.

OPERATING and MAINTENANCE INSTRUCTIONS

Model: 120PH and 121PH “D” Series Proof/Hot Cabinets

REPLACEMENT PARTS:

| DESCRIPTION | 120 VOLT | 208 VOLT | 240 VOLT |
|--------------------------|-------------|-------------|-------------|
| Proof/Hot Unit (121PH) | PHU-747-071 | PHU-747-072 | PHU-747-073 |
| Proof/Hot Unit (120PH) | PHU-747-077 | PHU-747-078 | PHU-747-079 |
| Heater (Reservoir) | 0811-285 | 0811-286 | 0811-287 |
| Pan (Reservoir) | 1017-097 | 1017-097 | 1017-097 |
| Heater (Air) | 0811-214-K | 0811-250 | 0811-215 |
| Thermostat Kit | 0848-062-K | 0848-062-K | 0848-062-K |
| Thermometer Kit (Analog) | 5238-030-K | 5238-030-K | 5238-030-K |
| Power Cord | 0810-065-1 | 0810-039 | 0810-039 |
| Proof & Heat Lights | 0766-093 | 0766-093-1 | 0766-093-1 |
| Power Light | 0766-094 | 0766-095 | 0766-095 |
| Switch (Power) | 0808-116-K | 0808-116-K | 0808-116-K |
| Switch (Mode Selection) | 0808-117-K | 0808-117-K | 0808-117-K |
| Blower Kit | 0769-180-K | 0769-182-K | 0769-182-K |
| Drip Pan Kit (121 PH) | 1017-058 | 1017-058 | 1017-058 |
| Drip Pan Kit (120 PH) | 1017-082 | 1017-082 | 1017-082 |
| Terminal Block | 0852-091 | 0852-091 | 0852-091 |

CABINET PARTS:

| | | | |
|---------------|---------------|----------------------|------------|
| Door Assembly | 0576-081-BL-K | Wire Angles | 0621-281-K |
| Door Gasket | 0861-256-K | Posts-Angle | 0692-194 |
| Door Latch | 1006-154-01-K | Rack Insert (-1818D) | 1170-209 |
| Door Hinge | 0519-104-K | | |

TROUBLE-SHOOTING CHART:

| FAILURE | POSSIBLE CAUSE |
|---|---|
| 1. Indicator lights do NOT light. | 1a. Circuit breaker/fuse to wall outlet is blown. 1b. Cord is unplugged from wall outlet or cabinet. 1c. Switch is “OFF”. |
| 2. Unit does not heat. | 2a. Thermostat set too low or is “OFF”. 2b. Switch is “OFF”. |
| 3. Unit gets too hot or won’t shut off. | 3a. Defective electrical parts. UNPLUG UNIT FROM WALL OUTLET. |
| 4. Humidity is low | 4a. Water in pan may be low 4b. Thermostat set too low |
| 5. Blower does not work or makes noise. | 5a. Defective blower. |
| 6. GFCI device trips. | 6. Plug the cabinet into a non-GFCI outlet and set the temperature control to its maximum. Let the cabinet run for about 1 hour to dry out the heating element from any moisture that may have been absorbed. |

NOTE: Optional digital thermometer will flash if cabinet temperature is below 140°F or above 250°F.

Call the factory if you need different settings.

If cause is none of the above, refer to our list of Authorized Service Centers, FL-1400.

Call Toll-free: 877-CRES COR (273-7267) • Fax: 800-822-0393 • www.crescor.com

| | |
|----------------------|----------------|
| Proof/Hot Cabinets | FL-2306 |
| Rev. 11 (10/2021) | Page 4 of 4 |

 **CRES COR®**
5925 Heisley Road • Mentor, OH 44060-1833

OPERATING and MAINTENANCE INSTRUCTIONS

Model: 120PH and 121PH “D” Series Proof/Hot Cabinets

